

Table of Contents

Navigation / Document Conventions	v
Table of Contents	vii
List of Figures	xvii
List of Tables	xviii
1 Introduction.....	1
Features	1
Software Version Requirements.....	3
Where to Start?	3
2 Installation.....	5
Anti-static procedures	5
Loading firmware.....	5
Mounting	5
Location in Airframe	6
Orientation	6
Sizes & Weights.....	6
Vibration Isolation.....	7
Connectors	8
Connectors, Pins, and Crimping Tools	12
Power	17
Measuring Main Voltage.....	17
Minimum/Maximum Voltages	18
Current Draw.....	18
Ground loops.....	18
RC Receiver	19
MP1028 ^{g2} /MP2028 ^{g2} /MP2128g2 / MP2128HELI2.....	20
RC Signals from the Receiver	20
RC Autopilot By-pass Devices.....	21
Servo Board.....	21

Servo Board Power Input	22
Servo Voltage Sense.....	22
Measuring Servo Voltage	22
Servo Board Power Capabilities	23
GPS.....	23
Transition Cable Location.....	24
GPS Backup Battery	25
Mounting the GPS antenna	26
External GPS receiver.....	27
AGL	29
MP - AGL	29
Current Draw.....	30
Mounting the AGL	31
Noise.....	32
AGL Scaling	34
Compass	35
Serial COM Port.....	35
Pitot tube	36
Static Air Inlet.....	37
Altitude Sensor	37
Speed controller.....	37
Radio Modems.....	37
Wiring Diagrams	38
3 Communicating with your MicroPilot Autopilot.....	43
Serial port	43
Software.....	43
Using HyperTerminal & Similar	44
Default Settings.....	44
Connect to PC.....	44
Using HORIZON ^{mp}	47
Installing HORIZON ^{mp}	47
Configuring HORIZON ^{mp}	48
Working with .vrs files.....	49
4 Servo configurations	55

About Servo Configurations	55
Making Servo Adjustments	62
Servo Travel Modes	64
Servo Travel Config Fields	65
Coarse Servo Mixing	66
Custom Servo Mixes	67
CH5 Setup – CIC/PIC	68
Failsafe Setup	69
5 Post Installation Checks.....	71
Follow these Steps.....	71
Vibration Analyser.....	76
Fly Away Prevention Measures.....	80
HORIZON ^{mp} Preparation for First Flight	82
The Next Step	82
Test Fly in PIC	83
6 Operating your MicroPilot Autopilot.....	85
Power on	85
Fake GPS Lock	86
Preflight Checks.....	87
Cold/Warm Soak	87
Takeoff.....	89
Manual takeoff.....	89
Current Altitude = 0 Conditions.....	89
Landing	89
Approach Speed, Final Reduce Speed, and Minimum Target Speed	89
GCS CIC Modes	90
How to choose modes.....	90
RPV Mode.....	90
Failures in RPV Mode	90
Fly by Camera.....	91
Orbit by Camera.....	92
Priority of Control Modes	92
Fatal Errors	92
Multiple Fatal Errors	93

Indication.....	93
AutoPilot Action.....	94
User-Defined Fatal Errors	108
GPS Error Messages	109
Warnings	110
Multiple Warnings.....	111
Indication.....	111
User-Defined Warnings.....	119
Clearing a User-defined Warning Code	120
Temperature Effects	122
Data log	122
7 Setting Parameters	125
Main Initial Settings.....	125
Flight tab	125
Servos tab.....	130
Sensors tab.....	132
GPS tab	134
Other tab	136
Heli tab: Kalman Filter Parameters	138
GPS antenna position	139
On-ground detection.....	140
Help with Setting up Fields / Features.....	140
8 PID Feedback Loops.....	141
PID Loops	141
About PIDs.....	143
PTerm	143
ITerm	143
DTerm.....	144
Feed Forward	146
PID Loops with Feed Forward	147
New Feed Forward Terms in 3.6	147
Input Max/Min & Result Anti-windup Max/Min	148
Setting Gains	148
Feedback Loop Configuration	149

Example: Level Flight.....	149
Example: Pre-Takeoff.....	150
Example: Climb	150
Example: Descent	151
9 Stability Derivatives & the HORIZON^{mp} Simulator	153
AVL Text Editor.....	153
Opening a Project	153
Generating stability derivatives.....	154
Export Derivatives to DFN Editor.....	157
10 MicroPilot Autopilot Setup	159
Tuning Feedback Loops.....	159
The gain setting process for fixed wing aircraft	160
Recording PID Values	160
To Start	162
The Inner Loops.....	163
Rapid Rolling side to side (several times each second).....	164
Fast Pitch Oscillations (1 Hz or more)	164
Rapid Yaw Oscillations (1 Hz or more)	164
Navigation Loops	164
Navigation is sloppy	165
S-Turning or Slow rolling oscillations	165
Turns sharper in one direction than the other	166
Altitude and Airspeed Control.....	167
Lots of overshoot on a climb.....	167
Lots of overshoot on a descent	167
Flies consistently lower/higher than the desired altitude	168
Always flies slower or faster than the desired airspeed	168
Doesn't hold airspeed well.....	168
Descends too slowly or climbs instead of descending	168
Flies too fast/slow when climbing	169
Descending when the UAV should be climbing	169
Slow Pitch Oscillation (several seconds)	169
Slow Altitude Oscillations (several seconds)	169
Slow Airspeed Oscillations (several seconds)	170

Slow Airspeed Oscillations combined with Slow Altitude Oscillations (ten or tens of seconds).....	170
After Each Tuning Flight.....	171
Using Gain Schedules	172
Autonomous Takeoff Tips	175
UAV Pitches Up or Down immediately from Catapult	175
UAV pitches down as soon as climb speed is reached.....	176
Adjusting Gains for Autonomous Landing	177
Attempting Multiple Circuit Approaches	177
In-flight Gain adjustment	178
Gains panel.....	179
MP Status Monitor	180
Graphs	181
Other buttons	183
11 Commands	185
Data Types	186
Unit Conversions.....	187
Comments in Fly Files	187
Reaching waypoints.....	188
Relative Waypoints and Origin	189
Basic Flight Commands	189
Two Stage Glideslope	209
Advanced Flight Commands	216
Calculation Commands.....	226
Thread and Pattern Commands	230
Skip commands	242
Wait Commands	244
Skip & WaitCommands for Heading Fields.....	247
In-flight Failure Patterns	249
Recoverable/Unrecoverable	250
Failure Timeouts	251
Control failure.....	251
Fatal error	251
Loss of GPS signal.....	252
Loss of engine power	254

Low battery voltage	255
RC link failure.....	256
HORIZON ^{mp} communication link failure	256
Special Field Definitions for Fly Files.....	257
Compiler	260
Run Time Errors.....	260
12 MicroPilot Autopilot Fields.....	261
Sign Conventions.....	262
Autopilot Units.....	263
Setup Fields.....	265
Launch	265
Flight.....	271
Recovery	276
Servos & Mixing	279
Sensors.....	286
GPS	291
<i>HORIZON^{mp} GCS & Terminal communication</i>	294
Failures	299
Limits	302
Batteries.....	306
Integrators.....	307
Camera Targeting	307
LRC.....	311
<i>MP2028^{XP}(Target)</i>	311
Video Overlay.....	312
VRS Locking	312
Runway Fields.....	313
Data log Configuration Fields	314
PID Feedback Loops.....	322
Watchdog Fields	330
Stall / Tumble Recovery Fields.....	330
PID Loops for Stall & Tumble Recovery	333
Glide Landing Function	338
Simulator Calibration Override	339

Servos.....	340
Other.....	340
State Fields.....	341
Attitude.....	341
Other sensors.....	344
Kalman Filter Estimates	347
High Precision Attitude	349
<i>GPS & Navigation</i>	349
HORIZON ^{mp} GCS and Terminal Communication.....	357
Status.....	361
Table Lookup Functions	369
Servo & Flight Control Fields.....	370
Command State	374
Raw Sensors.....	380
Feedback Loop State	383
Origin Fields	387
Transponder Setup Fields	388
Other State Fields	389
Bind Feature State Fields.....	392
Watchdog State Fields	393
Helicopter Specific Fields	394
13 Setup Program	399
Setting Hexadecimal values	401
14 Data log & Telemetry	402
About the Data log	402
Starting/Stopping.....	402
Resetting/clearing	403
Protecting Data log.....	403
Buffering.....	403
Data log Capacity & Recording Rate.....	404
Log Recording Time	404
Circular data log recording	405
Backward filter.....	405
List of Data log fields	405

	Status fields decoded	410
	GPS Time	412
	Custom Data log Features	413
	User-defined Data log Fields	413
	Using Unused Data log Servo Fields to Record Other Values.....	414
	Telemetry.....	414
	User Defined	414
	GPS time.....	415
	Standard Telemetry.....	415
	MP-3X Status	419
	Camera Telemetry	420
15	Loading New Code.....	423
	MP2028g Small flash chip firmware	423
	Updating software	423
	Last Firmware Versions available.....	423
	Correct Firmware type for Autopilot.....	424
	Installation.....	426
16	Problem Solving.....	429
	Initialization	429
	GPS	429
	Servos.....	432
	Takeoff.....	432
	Flight.....	434
	Circuit and Landing	434
	Radio Reception	435
	Other Problems.....	436
	After a Crash or Hard Landing.....	438
	Further Information	438
17	RMA's and SUPPORT	439
	Warranty	439
	RMA's	440
	RMA Standards.....	441
	Charges	442
	RMA Services	444

Support	446
Support By TeamViewer	448
Support By Skype	449
Support Site Content	449
Finding Your Autopilot's Serial Number	449
List of Serial Number Prefixes	450
Primary COM port	463
UARTs	463
CMOS vs RS232 Levels	464
About the Watchdog Feature	469
Watchdog Failure Signal	469
Watchdog Trigger Conditions	470
Testing	470
Watchdog Fields	470
Autopilot	471
HORIZON ^{mp} and other GUI	471
XTENDER	471

Appendices

A.	TPU Channels and CAN Lines	455
	MP1028g/MP2028g&MP1028g2/MP2028g2/MP2128g2/MP2128HELI2	455
	MP1028g2/MP2028g2/MP2128g2/MP2128HELI2 Only	456
B.	Serial Ports & UARTs	463
	Available Ports	463
	RS485	464
C.	MP1028^g Appendix	465
D.	Watchdog Feature	469
E.	Open source code	471
Index	474